



**Full credit is given to the above companies including the Operating System (OS) that this PDF file was generated!**

***Rocky Enterprise Linux 9.2 Manual Pages on command 'pvresize.8'***

\$ man pvresize.8

PVRESIZE(8)

System Manager's Manual

PVRESIZE(8)

#### NAME

pvresize - Resize physical volume(s)

#### SYNOPSIS

pvresize position\_args

[ option\_args ]

#### DESCRIPTION

pvresize resizes a PV. The PV may already be in a VG and may have active LVs allocated on it.

#### USAGE

pvresize PV ...

[ --setphysicalvolumesize Size[m|UNIT] ]

[ --reportformat basic|json ]

[ COMMON\_OPTIONS ]

Common options for lvm:

[ -d|--debug ]

[ -h|--help ]

[ -q|--quiet ]

[ -t|--test ]

[ -v|--verbose ]

[ -y|--yes ]

[ --commandprofile String ]

[ --config String ]

```
[ --driverloaded y|n ]  
[ --lockopt String ]  
[ --longhelp ]  
[ --nolocking ]  
[ --profile String ]  
[ --version ]
```

## OPTIONS

--commandprofile String

The command profile to use for command configuration. See lvm.conf(5) for more information about profiles.

--config String

Config settings for the command. These override lvm.conf settings. The String arg uses the same format as lvm.conf, or may use section/field syntax. See lvm.conf(5) for more information about config.

-d|--debug ...

Set debug level. Repeat from 1 to 6 times to increase the detail of messages sent to the log file and/or syslog (if configured).

--driverloaded y|n

If set to no, the command will not attempt to use device-mapper. For testing and debugging.

-h|--help

Display help text.

--lockopt String

Used to pass options for special cases to lvmlockd. See lvmlockd(8) for more information.

--longhelp

Display long help text.

--nolocking

Disable locking.

--profile String

An alias for --commandprofile or --metadataprofile, depending on the command.

-q|--quiet ...

Suppress output and log messages. Overrides --debug and --verbose. Repeat once to

also suppress any prompts with answer 'no'.

#### --reportformat basic|json

Overrides current output format for reports which is defined globally by the report/output\_format setting in lvm.conf. basic is the original format with columns and rows. If there is more than one report per command, each report is prefixed with the report name for identification. json produces report output in JSON format. See lvmreport(7) for more information.

#### --setphysicalvolumesize Size[m|UNIT]

Overrides the automatically detected size of the PV. Use with care, or prior to reducing the physical size of the device.

#### -t|--test

Run in test mode. Commands will not update metadata. This is implemented by disabling all metadata writing but nevertheless returning success to the calling function. This may lead to unusual error messages in multi-stage operations if a tool relies on reading back metadata it believes has changed but hasn't.

#### -v|--verbose ...

Set verbose level. Repeat from 1 to 4 times to increase the detail of messages sent to stdout and stderr.

#### --version

Display version information.

#### -y|--yes

Do not prompt for confirmation interactively but always assume the answer yes. Use with extreme caution. (For automatic no, see -qq.)

## VARIABLES

### PV

Physical Volume name, a device path under /dev. For commands managing physical extents, a PV positional arg generally accepts a suffix indicating a range (or multiple ranges) of physical extents (PEs). When the first PE is omitted, it defaults to the start of the device, and when the last PE is omitted it defaults to end. Start and end range (inclusive): PV[:PE-PE]... Start and length range (counting from 0): PV[:PE+PE]...

### String

See the option description for information about the string content.

## Size[UNIT]

Size is an input number that accepts an optional unit. Input units are always treated as base two values, regardless of capitalization, e.g. 'k' and 'K' both refer to 1024. The default input unit is specified by letter, followed by |UNIT. UNIT represents other possible input units: bBsSkKmMgGtTpPeE. b|B is bytes, s|S is sectors of 512 bytes, k|K is KiB, m|M is MiB, g|G is GiB, t|T is TiB, p|P is PiB, e|E is EiB. (This should not be confused with the output control --units, where capital letters mean multiple of 1000.)

## ENVIRONMENT VARIABLES

See lvm(8) for information about environment variables used by lvm. For example, LVM\_VG\_NAME can generally be substituted for a required VG parameter.

## NOTES

pvresize will refuse to shrink a PV if it has allocated extents beyond the new end.

## EXAMPLES

Expand a PV after enlarging the partition.

```
pvresize /dev/sda1
```

Shrink a PV prior to shrinking the partition (ensure that the PV size is appropriate for the intended new partition size).

```
pvresize --setphysicalvolumesize 40G /dev/sda1
```

## SEE ALSO

lvm(8) lvm.conf(5) lvmconfig(8)

pvchange(8) pvck(8) pvcreate(8) pvdisk(8) pvmove(8) pvremove(8) pvresize(8) pvs(8) pvs?can(8)

vgcfgbackup(8) vgcfgrestore(8) vgchange(8) vgck(8) vgcreate(8) vgconvert(8) vgdisplay(8)  
vgexport(8) vgextend(8) vgimport(8) vgimportclone(8) vgmerge(8) vgmknodes(8) vgreduce(8)  
vgremove(8) vgrename(8) vgs(8) vgscan(8) vgsplit(8)

lvcreate(8) lvchange(8) lvconvert(8) lvdisplay(8) lvextend(8) lvreduce(8) lvremove(8)

lvrename(8) lvresize(8) lvs(8) lvscan(8)

lvm-fullreport(8) lvm-lvpoll(8) lvm2-activation-generator(8) blkdeactivate(8) lvmddump(8)

dmeventd(8) lvmpolld(8) lvmlockd(8) lvmlockctl(8) cmirrord(8) lvmdbusd(8)

lvmsystemid(7) lvmreport(7) lvmraid(7) lvmthin(7) lvmcache(7)