



*Full credit is given to the above companies including the OS that this PDF file was generated!*

### ***Rocky Enterprise Linux 9.2 Manual Pages on command 'qmikli.1'***

**\$ man qmikli.1**

QMICLI(1) User Commands QMICLI(1)

NAME

qmikli - Control QMI devices

DESCRIPTION

Usage:

qmikli [OPTION??.?] - Control QMI devices

Help Options:

-h, --help

Show help options

--help-all

Show all help options

--help-dms

Show Device Management Service options

--help-nas

Show Network Access Service options

--help-wds

Show Wireless Data Service options

--help-pbm

Show Phonebook Management options

--help-pdc

Show platform device configurations options

--help-uim

Show User Identity Module options

--help-sar

Show Specific Absorption Rate options

--help-wms

Show Wireless Messaging Service options

--help-wda

Show Wireless Data Administrative options

--help-voice

Show Voice Service options

--help-loc

Show location options

--help-qos

Show Quality of Service options

--help-gas

Show General Application Service options

--help-gms

Show General Modem Service options

--help-dsd

Show Data System Determination options

--help-dpm

Show Data Port Mapper Service options

--help-fox

Show Foxconn Modem Service options

--help-link-management

Show link management specific options

--help-qmiwwan

Show qmi\_wwan driver specific options

DMS options:

--dms-get-ids

Get IDs

--dms-get-capabilities

Get capabilities

--dms-get-manufacturer

Get manufacturer

--dms-get-model

Get model

--dms-get-revision

Get revision

--dms-get-msisdn

Get MSISDN

--dms-get-power-state

Get power state

--dms-uim-set-pin-protection=[(PIN|PIN2),(disable|enable),(current PIN)]

Set PIN protection in the UIM

--dms-uim-verify-pin=[(PIN|PIN2),(current PIN)]

Verify PIN

--dms-uim-unblock-pin=[(PIN|PIN2),(PUK),(new PIN)]

Unblock PIN

--dms-uim-change-pin=[(PIN|PIN2),(old PIN),(new PIN)]

Change PIN

--dms-uim-get-pin-status

Get PIN status

--dms-uim-get-iccid

Get ICCID

--dms-uim-get-imsi

Get IMSI

--dms-uim-get-state

Get UIM State

--dms-uim-get-ck-status=[(pn|pu|pp|pc|pf)]

Get CK Status

--dms-uim-set-ck-protection=[(pn|pu|pp|pc|pf),(disable),(key)]

Disable CK protection

--dms-uim-unblock-ck=[(pn|pu|pp|pc|pf),(key)]

Unblock CK

--dms-get-hardware-revision

Get the HW revision

--dms-get-operating-mode

Get the device operating mode

--dms-set-operating-mode=[(Operating mode)]

Set the device operating mode

--dms-get-time

Get the device time

--dms-get-prl-version

Get the PRL version

--dms-get-activation-state

Get the state of the service activation

--dms-activate-automatic=[Activation Code]

Request automatic service activation

--dms-activate-manual=[SPC,SID,MDN,MIN]

Request manual service activation

--dms-get-user-lock-state

Get the state of the user lock

--dms-set-user-lock-state=[(disable|enable),(current lock code)]

Set the state of the user lock

--dms-set-user-lock-code=[(old lock code),(new lock code)]

Change the user lock code

--dms-read-user-data

Read user data

--dms-write-user-data=[(User data)]

Write user data

--dms-read-eri-file

Read ERI file

--dms-restore-factory-defaults=[(Service Programming Code)]

Restore factory defaults

--dms-validate-service-programming-code=[(Service Programming Code)]

Validate the Service Programming Code

--dms-set-firmware-id

Set firmware id

--dms-get-band-capabilities

Get band capabilities

--dms-get-factory-sku

Get factory stock keeping unit

--dms-list-stored-images

List stored images

--dms-select-stored-image=[modem#,pri#] where # is the index

Select stored image

--dms-delete-stored-image=[modem#|pri#] where # is the index

Delete stored image

--dms-get-firmware-preference

Get firmware preference

--dms-set-firmware-preference=["key=value,..."]

Set firmware preference (required keys: firmware-version, con?

fig-version, carrier; optional keys: modem-storage-index, over?

ride-download=yes)

--dms-get-boot-image-download-mode

Get boot image download mode

--dms-set-boot-image-download-mode=[normal|boot-and-recovery]

Set boot image download mode

--dms-get-software-version

Get software version

--dms-set-fcc-authentication

Set FCC authentication

--dms-get-supported-messages

Get supported messages

--dms-hp-change-device-mode=[fastboot]

Change device mode (HP specific)

--dms-swi-get-current-firmware

Get Current Firmware (Sierra Wireless specific)

--dms-swi-get-usb-composition

Get current and supported USB compositions (Sierra Wireless specific)

--dms-swi-set-usb-composition=[#]

Set USB composition (Sierra Wireless specific)

--dms-foxconn-change-device-mode=[fastboot-ota|fastboot-online]

Change device mode (Foxconn specific)

--dms-foxconn-get-firmware-version=[firmware-mcfg-apps|firmware-mcfg|apps]

Get firmware version (Foxconn specific)

--dms-foxconn-set-fcc-authentication=[magic]

Set FCC authentication (Foxconn specific)

--dms-foxconn-set-fcc-authentication-v2=[magic-string,magic-number]

Set FCC authentication (Foxconn specific, v2)

--dms-get-mac-address=[wlan|bt]

Get default MAC address

--dms-reset

Reset the service state

--dms-noop

Just allocate or release a DMS client. Use with '--client-no-release-cid' and/or '--client-cid'

NAS options:

--nas-get-signal-strength

Get signal strength

--nas-get-signal-info

Get signal info

--nas-get-tx-rx-info=[(Radio Interface)]

Get TX/RX info

--nas-get-home-network

Get home network

--nas-get-serving-system

Get serving system

--nas-get-system-info  
Get system info

--nas-get-technology-preference  
Get technology preference

--nas-get-preferred-networks  
Get preferred networks

--nas-set-preferred-networks=[[MCCMNC,access\_tech],...]  
Set preferred networks list

--nas-get-system-selection-preference  
Get system selection preference

--nas-set-system-selection-preference=[cdma-1x|cdma-1xe|gsm|umts|lte|td-scdma][,[automatic|manual=MC?CMNC]]  
Set system selection preference

--nas-network-scan  
Scan networks

--nas-get-cell-location-info  
Get Cell Location Info

--nas-force-network-search  
Force network search

--nas-get-operator-name  
Get operator name data

--nas-get-plmn-name=[mccmnc]  
Get plmn name data

--nas-get-lte-cphy-ca-info  
Get LTE Cphy CA Info

--nas-get-rf-band-info  
Get RF Band Info

--nas-get-drx  
Get DRX

--nas-get-supported-messages  
Get supported messages

--nas-swi-get-status

Get status ((Sierra Wireless specific)

--nas-reset

Reset the service state

--nas-noop

Just allocate or release a NAS client. Use with `--client-no-re?

lease-cid' and/or `--client-cid'

WDS options:

--wds-start-network=["key=value,..."]

Start network (allowed keys: apn, 3gpp-profile, 3gpp2-profile, auth (PAP|CHAP|BOTH), username, password, autoconnect=yes, ip-type (4|6))

--wds-follow-network

Follow the network status until disconnected. Use with `--wds-start-network'

--wds-stop-network=[Packet data handle] OR [disable-autoconnect]

Stop network

--wds-get-current-settings

Get current settings

--wds-get-packet-service-status

Get packet service status

--wds-get-packet-statistics

Get packet statistics

--wds-get-data-bearer-technology

Get data bearer technology

--wds-get-current-data-bearer-technology

Get current data bearer technology

--wds-go-dormant

Make the active data connection go dormant

--wds-go-active

Make the active data connection go active

--wds-get-dormancy-status

Get the dormancy status of the active data connection

--wds-create-profile=["(3gpp|3gpp2)[,key=value,..."]

Create new profile using first available profile index (optional keys: name, apn, pdp-type (IP|PPP|IPV6|IPV4V6), auth (NONE|PAP|CHAP|BOTH), username, password, context-num, no-roaming? ing=yes, disabled=yes)

--wds-swi-create-profile-indexed=["(3gpp|3gpp2),#[,key=value,...]"]

Create new profile at specified profile index [Sierra Wireless specific] (optional keys: name, apn, pdp-type (IP|PPP|IPV6|IPV4V6), auth (NONE|PAP|CHAP|BOTH), username, password, context-num, no-roaming=yes, disabled=yes)

--wds-modify-profile=["(3gpp|3gpp2),#[,key=value,...]"]

Modify existing profile (optional keys: name, apn, pdp-type (IP|PPP|IPV6|IPV4V6), auth (NONE|PAP|CHAP|BOTH), username, password, context-num, no-roaming=yes, disabled=yes)

--wds-delete-profile=["(3gpp|3gpp2),#"]

Delete existing profile

--wds-get-profile-list=[3gpp|3gpp2]

Get profile list

--wds-get-default-profile-number=[3gpp|3gpp2]

Get default profile number

--wds-set-default-profile-number=["(3gpp|3gpp2),#"]

Set default profile number

--wds-get-default-settings=[3gpp|3gpp2]

Get default settings

--wds-get-autoconnect-settings

Get autoconnect settings

--wds-set-autoconnect-settings=["(enabled|disabled|paused)[,(roaming-allowed|home-only)]]

Set autoconnect settings (roaming settings optional)

--wds-get-supported-messages

Get supported messages

--wds-reset

Reset the service state

--wds-bind-data-port=[a2-mux-rmnet0-7]#]

Bind data port to controller device to be used with

`--client-no-release-cid'

--wds-bind-mux-data-port=["key=value,..."]

Bind qmux data port to controller device (allowed keys: mux-id, ep-type (undefined|hsusb|pcie|embedded|bam-dmux), ep-iface-number) to be used with `--client-no-release-cid'

--wds-set-ip-family=[4|6]

Set IP family

--wds-get-channel-rates

Get channel data rates

--wds-get-lte-attach-parameters

Get LTE attach parameters

--wds-get-max-lte-attach-pdn-num

Get the maximum number of LTE attach PDN

--wds-get-lte-attach-pdn-list

Get the list of LTE attach PDN

--wds-set-lte-attach-pdn-list=[#,#,...]

Set the list of LTE attach PDN

--wds-noop

Just allocate or release a WDS client. Use with `--client-no-release-cid' and/or `--client-cid'

PBM options:

--pbm-get-all-capabilities

Get all phonebook capabilities

--pbm-noop

Just allocate or release a PBM client. Use with `--client-no-release-cid' and/or `--client-cid'

PDC options:

--pdc-list-configs=[(platform|software)]

List all configs

--pdc-delete-config=[(platform|software),ConfigId]

Delete config

--pdc-activate-config=[(platform|software),ConfigId]

Activate config

--pdc-deactivate-config=[(platform|software),ConfigId]

Deactivate config

--pdc-load-config=[Path to config]

Load config to device

--pdc-monitor-refresh

Watch for refresh indications

--pdc-noop

Just allocate or release a PDC client. Use with '--client-no-re?

lease-cid' and/or '--client-cid'

UIM options:

--uim-set-pin-protection=[(PIN1|PIN2|UPIN),(disable|enable),(current PIN)]

Set PIN protection

--uim-verify-pin=[(PIN1|PIN2|UPIN),(current PIN)]

Verify PIN

--uim-unblock-pin=[(PIN1|PIN2|UPIN),(PUK),(new PIN)]

Unblock PIN

--uim-change-pin=[(PIN1|PIN2|UPIN),(old PIN),(new PIN)]

Change PIN

--uim-read-transparent=[0xNNNN,0xNNNN,...]

Read a transparent file given the file path

--uim-get-file-attributes=[0xNNNN,0xNNNN,...]

Get the attributes of a given file

--uim-read-record=["key=value,..."]

Read a record from given file (allowed keys: record-number, record-length, file ([0xNNNN-0xNNNN,...])

--uim-get-card-status

Get card status

--uim-get-supported-messages

Get supported messages

--uim-sim-power-on=[(slot number)]

Power on SIM card

--uim-sim-power-off=[(slot number)]

Power off SIM card

--uim-change-provisioning-session=["key=value,..."]

Change provisioning session (allowed keys: session-type, activate, slot, aid)

--uim-get-slot-status

Get slot status

--uim-switch-slot=[(slot number)]

Switch active physical slot

--uim-monitor-slot-status

Watch for slot status indications

--uim-reset

Reset the service state

--uim-monitor-refresh-file=[0xNNNN,0xNNNN,...]

Watch for REFRESH events for given file paths

--uim-monitor-refresh-all

Watch for REFRESH events for any file

--uim-get-configuration

Get personalization status of the modem

--uim-depersonalization=[(feature),(operation),(control key)],(slot number)]

Deactivates or unblocks personalization feature

--uim-noop

Just allocate or release a UIM client. Use with '--client-no-release-cid' and/or '--client-cid'

SAR options:

--sar-rf-get-state

Get RF state

--sar-rf-set-state=[(state number)]

Set RF state.

--sar-noop

Just allocate or release a SAR client. Use with '--client-no-release-cid' and/or '--client-cid'

## WMS options:

--wms-get-supported-messages

Get supported messages

--wms-get-routes

Get SMS route information

--wms-set-routes=["key=value,..."]

Set SMS route information (keys: type, class, storage, receipt-action)

--wms-reset

Reset the service state

--wms-noop

Just allocate or release a WMS client. Use with '--client-no-release-cid' and/or '--client-cid'

## WDA options:

--wda-set-data-format=["key=value,..."]

Set data format (allowed keys: link-layer-protocol (802-3|raw-ip), ul-protocol (disabled|tlp|qc-ncm|mbim|rndis|qmap|qmapv5), dl-protocol (disabled|tlp|qc-ncm|mbim|rndis|qmap|qmapv5), dl-datagram-max-size, dl-max-datagrams, ep-type (undefined|hsusb|pcie|embedded), ep-iface-number, ul-datagram-max-size, ul-max-datagrams)

--wda-get-data-format=["key=value,..."]

Get data format (allowed keys: ep-type (undefined|hsusb|pcie|embedded), ep-iface-number); also allows empty key list

--wda-get-supported-messages

Get supported messages

--wda-noop

Just allocate or release a WDA client. Use with '--client-no-release-cid' and/or '--client-cid'

## VOICE options:

--voice-get-config

Get Voice service configuration

--voice-get-supported-messages

Get supported messages

--voice-noop

Just allocate or release a VOICE client. Use with

`--client-no-release-cid' and/or `--client-cid'

LOC options:

--loc-session-id=[ID]

Session ID for the LOC session

--loc-start

Start location gathering

--loc-stop

Stop location gathering

--loc-get-position-report

Get position reported by the location module

--loc-get-gnss-sv-info

Show GNSS space vehicle info

--loc-timeout=[SECS]

Maximum time to wait for information in `--loc-get-position-report' and `--loc-get-gnss-sv-info' (default 30s)

--loc-follow-position-report

Follow all position updates reported by the location module indefinitely

--loc-follow-gnss-sv-info

Follow all GNSS space vehicle info updates reported by the location module indefinitely

--loc-follow-nmea

Follow all NMEA trace updates reported by the location module indefinitely

--loc-delete-assistance-data

Delete positioning assistance data

--loc-get-nmea-types

Get list of enabled NMEA traces

--loc-set-nmea-types=[type1|type2|type3...]

Set list of enabled NMEA traces

--loc-get-operation-mode

Get operation mode

--loc-set-operation-mode=[default|msb|msa|standalone|cellid|wwan]

Set operation mode

--loc-get-engine-lock

Get engine lock status

--loc-set-engine-lock=[none|mi|mt|all]

Set engine lock status

--loc-noop

Just allocate or release a LOC client. Use with `--client-no-re?

lease-cid' and/or `--client-cid'

QoS options:

--qos-get-flow-status=[QoS ID]

Get QoS flow status

--qos-get-network-status

Gets the network status

--qos-swi-read-data-stats=[APN ID]

Read data stats (Sierra Wireless specific)

--qos-reset

Reset the service state

--qos-noop

Just allocate or release a QOS client. Use with `--client-no-re?

lease-cid' and/or `--client-cid'

GAS options:

--gas-dms-set-usb-composition=[pid]

Sets the USB composition

--gas-dms-get-usb-composition

Gets the current USB composition

--gas-dms-get-firmware-list

Gets the list of stored firmware

--gas-dms-get-active-firmware

Gets the currently active firmware

--gas-dms-set-active-firmware=[index]

Sets the active firmware index

--gas-noop

Just allocate or release a GAS client. Use with `--client-no-re?

lease-cid' and/or `--client-cid'

GMS options:

--gms-test-get-value

Gets test value

--gms-test-set-value=[mandatory-value],[optional-value]]

Sets test value

--gms-noop

Just allocate or release a GMS client. Use with `--client-no-re?

lease-cid' and/or `--client-cid'

DSD options:

--dsd-get-apn-info=[(type)]

Gets the settings associated to a given APN type

--dsd-set-apn-type=[(name), (type1|type2|type3...)]

Sets the types associated to a given APN name

--dsd-get-system-status

Gets system status

--dsd-noop

Just allocate or release a DSD client. Use with `--client-no-re?

lease-cid' and/or `--client-cid'

DPM options:

--dpm-open-port=["key=value,..."]

Open port (allowed-keys: ctrl-ep-type, ctrl-ep-iface-number,  
ctrl-port-name, hw-data-ep-type, hw-data-ep-iface-number,  
hw-data-rx-id, hw-data-tx-id, sw-data-ep-type,  
sw-data-ep-iface-number, sw-data-port-name)

--dpm-close-port

Close port

--dpm-noop

Just allocate or release a DPM client. Use with `--client-no-re?

lease-cid' and/or `--client-cid'

## FOX options:

`--fox-get-firmware-version=[firmware-mcfg-apps|firmware-mcfg|apps]`

Get firmware version

`--fox-noop`

Just allocate or release a FOX client. Use with `--client-no-re?`

`lease-cid'` and/or `--client-cid'`

## Link management options:

`--link-list=[IFACE]`

List links created from a given interface

`--link-add=[iface=IFACE,prefix=PREFIX[,mux-id=N][,flags=FLAGS]]`

Create new network interface link

`--link-delete=[link-iface=IFACE][,[mux-id=N]]`

Delete a given network interface link

`--link-delete-all=[IFACE]`

Delete all network interface links from the given interface

## qmi\_wwan specific options:

`-w, --get-wwan-iface`

Get the associated WWAN iface name

`-e, --get-expected-data-format`

Get the expected data format in the WWAN iface

`-E, --set-expected-data-format=[802-3|raw-ip|qmap-pass-through]`

Set the expected data format in the WWAN iface

## Application Options:

`-d, --device=[PATH|URI]`

Specify device path or QRTR URI (e.g. `qrtr://0`)

`--get-service-version-info`

Get service version info

`--device-set-instance-id=[Instance ID]`

Set instance ID

`--device-open-version-info`

Run version info check when opening device

`--device-open-sync`

Run sync operation when opening device

-p, --device-open-proxy

Request to use the 'qmi-proxy' proxy

--device-open-qmi

Open a cdc-wdm device explicitly in QMI mode

--device-open-mbim

Open a cdc-wdm device explicitly in MBIM mode

--device-open-auto

Open a cdc-wdm device in either QMI or MBIM mode (default)

--device-open-net=[net-802-3|net-raw-ip|net-qos-header|net-no-qos-header]

Open device with specific link protocol and QoS flags

--client-cid=[CID]

Use the given CID, don't allocate a new one

--client-no-release-cid

Do not release the CID when exiting

-v, --verbose

Run action with verbose logs, including the debug ones

--verbose-full

Run action with verbose logs, including the debug ones and personal info

sonal info

--silent

Run action with no logs; not even the error/warning ones

-V, --version

Print version

## COPYRIGHT

Copyright ? 2012-2022 Aleksander Morgado License GPLv2+: GNU GPL ver?

sion 2 or later <<http://gnu.org/licenses/gpl-2.0.html>>

This is free software: you are free to change and redistribute it.

There is NO WARRANTY, to the extent permitted by law.

## SEE ALSO

The full documentation for qmicli is maintained as a Texinfo manual.

If the info and qmicli programs are properly installed at your site,

the command

info qmicli

should give you access to the complete manual.

qmicli 1.32.2

November 2022

QMICLI(1)