

NAME

btattach – attach serial devices to BlueZ stack

SYNOPSIS

btattach [**-B** *device*] [**-A** *device*] [**-P** *protocol*] [**-R**]

DESCRIPTION

btattach is used to attach a serial UART to the Bluetooth stack as a transport interface.

OPTIONS

-B *device*, **--bredr** *device*

Attach a BR/EDR controller.

-A *device*, **--amp** *device*

Attach an AMP controller.

-P *protocol*, **--protocol** *protocol*

Specify the protocol type for talking to the device. Supported values are:

- **h4**
- **bcsp**
- **3wire**
- **h4ds**
- **ll**
- **ath3k**
- **intel**
- **bcm**
- **qca**

-R Set the device into raw mode (the kernel and bluetoothd will ignore it).