Red Hat Enterprise Linux Release 9.2 Manual Pages on 'nvme-seagate-get-ctrl-tele.1' command

$ man nvme-seagate-get-ctrl-tele.1

NVME-SEAGATE-GET-(1)   NVMe Manual   NVME-SEAGATE-GET-(1)

NAME

   nvme-seagate-get-ctrl-tele - Retrieve Seagate Controller-Initiated

   Telemetry in either hex-dump (default) or binary format

SYNOPSIS

   nvme seagate get-ctrl-tele <device> [OPTIONS]

DESCRIPTION

   This command will only work on Seagate devices supporting this feature.

   Not all commands work across all product families.

   The '<device>'parameter is mandatory and may be either an NVMe

   character device (ex: /dev/nvme0) or an nvme block device (ex:

   /dev/nvme0n1).

OPTIONS

   -n <NUM>, --namespace-id=<NUM>

      Desired namespace

   -b, --raw-binary

      Output in raw format

EXAMPLES

   Get the controller initiated telemetry log in hexdump or binary format

   for the specified device.

      # nvme seagate get-ctrl-tele /dev/nvme0

NVME

   Part of the nvme-user suite