Rocky Enterprise Linux 9.2 Manual Pages on command 'nvme-set-property.1'

$ man nvme-set-property.1

NVME-SET-PROPERTY(1)   NVMe Manual   NVME-SET-PROPERTY(1)

NAME

    nvme-set-property - Writes and shows the defined NVMe controller

    property for NVMe over Fabric

SYNOPSIS

    nvme set-property <device> [--offset=<offset> | -o <offset>]

                [--value=<val> | -v <val>]

DESCRIPTION

    Writes and shows the defined NVMe controller property for NVMe over

    Fabric.

OPTIONS

    -o, --offset

        The offset of the property.

-v

    --value: The value of the property to be set.

EXAMPLES

No examples (yet).

NVME

Part of the nvme-user suite