

Full credit is given to the above companies including the Operating System (OS) that this PDF file was generated!

Rocky Enterprise Linux 9.2 Manual Pages on command 'Ispcmcia.8'

\$ man Ispcmcia.8

PCCARDCTL(8)

System Manager's Manual

PCCARDCTL(8)

NAME

pccardctl - PCMCIA card control utility

Ispcmcia - display extended PCMCIA debugging information

SYNOPSIS

pccardctl [-V] [-v ...] command [socket]

Ispcmcia [-V] [-v ...] [socket]

DESCRIPTION

pccardctl is used to monitor and control the state of PCMCIA sockets. If a socket number is specified, the command will be applied to just one socket; otherwise, all sockets will be affected.

If pccardctl is executed by root, all commands are available. If it is executed by an un? priviledged user, only the informational commands are accessible.

Ispcmcia is an alias for pccardctl ls, provided for convenience.

COMMANDS

status

Display the current socket status flags.

config

Display the socket configuration, including power settings, interrupt and I/O window settings, and configuration registers. --not yet implemented

ident

Display card identification information, including product identification strings, manufacturer ID codes, and function ID codes. Not yet implemented for cardbus cards.

Use Ispci instead.

info

Much like the ident command, but its output is formatted as a series of Bourne-stype shell variable definitions for use in scripts. Not yet implemented for cardbus cards.

Is Display extended debugging information about the PCMCIA sockets and devices present in the system.

suspend

Shut down and then disable power for a socket.

resume

Restore power to a socket, and re-configure for use.

eject

Notify all client drivers that this card will be ejected, then cut power to the socket.

insert

Notify all client drivers that this card has just been inserted.

OPTIONS

- -V Show version information and exit.
- Increase the verbosity of the Is command. Giving this option twice increases ver?
 bosity further.

AUTHOR

Daniel Ritz - daniel.ritz@gmx.ch

based upon the original cardctl man page by

David Hinds - dahinds@users.sourceforge.net

pcmciautils 2005/10/22 PCCARDCTL(8)