



Full credit is given to the above companies including the OS that this PDF file was generated!

Red Hat Enterprise Linux Release 9.2 Manual Pages on 'nvme-reset.1' command

\$ man nvme-reset.1

NVME-RESET(1) NVMe Manual NVME-RESET(1)

NAME

nvme-reset - Reset the nvme controller.

SYNOPSIS

nvme reset <device>

DESCRIPTION

Requests NVMe controller reset. The <device> param is mandatory and must be an NVMe character device (ex: /dev/nvme0).

OPTIONS

None

EXAMPLES

? Resets the controller.

```
# nvme reset /dev/nvme0
```

NVME

Part of the nvme-user suite

NVMe 06/23/2023 NVME-RESET(1)