



*Full credit is given to the above companies including the OS that this PDF file was generated!*

### ***Rocky Enterprise Linux 9.2 Manual Pages on command 'nvme-dera-stat.1'***

**\$ man nvme-dera-stat.1**

NVME-DERA-STAT(1)                      NVMe Manual                      NVME-DERA-STAT(1)

#### NAME

nvme-dera-stat - Send NVMe Dera Device status and Additional SMART log page request, returns result and log

#### SYNOPSIS

nvme dera stat <device>

#### DESCRIPTION

Retrieves the NVMe Dera Device status and Additional SMART log page from the device and provides the returned structure.

The <device> parameter is mandatory and may be either the NVMe character device (ex: /dev/nvme0), or a namespace block device (ex: /dev/nvme0n1).

On success, the returned status and smart log structure are printed in a readable format.

#### OPTIONS

none

#### EXAMPLES

? Print the Dera Device status and Additional SMART log page in a

human readable format:

```
# nvme dera stat /dev/nvme0
```

NVME

Part of the nvme-user suite

NVMe	06/23/2023	NVME-DERA-STAT(1)
------	------------	-------------------