

Full credit is given to the above companies including the OS that this PDF file was generated!

Rocky Enterprise Linux 9.2 Manual Pages on command 'nvme-reset.1'

\$ man nvme-reset.1

NVME-RESET(1)

NVMe Manual

NVME-RESET(1)

NAME

nvme-reset - Reset the nvme controller.

SYNOPSIS

nvme reset <device>

DESCRIPTION

Requests NVMe controller reset. The <device> param is mandatory and must be an NVMe character device (ex: /dev/nvme0).

OPTIONS

None

EXAMPLES

? Resets the controller.

nvme reset /dev/nvme0

NVME

Part of the nyme-user suite

NVMe

06/23/2023

NVME-RESET(1)