



*Full credit is given to the above companies including the OS that this PDF file was generated!*

### ***Rocky Enterprise Linux 9.2 Manual Pages on command 'nvme-wdc-clear-assert-dump.1'***

***\$ man nvme-wdc-clear-assert-dump.1***

NVME-WDC-CLEAR-AS(1)      NVMe Manual      NVME-WDC-CLEAR-AS(1)

NAME

nvme-wdc-clear-assert-dump - Clears the assert dump (if present).

SYNOPSIS

nvme wdc clear-assert-dump <device>

DESCRIPTION

For the NVMe device given, sends the wdc vendor unique clear assert dump command.

The <device> parameter is mandatory and must be the NVMe character device (ex: /dev/nvme0).

This will only work on WDC devices supporting this feature. The command will not be executed on devices that don't support it.

OPTIONS

None

EXAMPLES

? Clears the assert dump (if present):

```
# nvme wdc clear-assert-dump /dev/nvme0
```

NVME

Part of the nvme-user suite

NVMe

06/23/2023

NVME-WDC-CLEAR-AS(1)