

**NAME**

virkeycode-atset2 – Key code values for atset2

**DESCRIPTION**

List of atset2 key code values, with corresponding linux key code names

- 1 (0x1)

Key name KEY\_F9

- 3 (0x3)

Key name KEY\_F5

- 4 (0x4)

Key name KEY\_F3

- 5 (0x5)

Key name KEY\_F1

- 6 (0x6)

Key name KEY\_F2

- 7 (0x7)

Key name KEY\_F12

- 9 (0x9)

Key name KEY\_F10

- 10 (0xa)

Key name KEY\_F8

- 11 (0xb)

Key name KEY\_F6

- 12 (0xc)

Key name KEY\_F4

- 13 (0xd)

Key name KEY\_TAB

- 14 (0xe)

Key name KEY\_GRAVE

- 15 (0xf)

Key name KEY\_KPEQUAL

- 17 (0x11)

Key name KEY\_LEFTALT

- 18 (0x12)

Key name KEY\_LEFTSHIFT

- 19 (0x13)

Key name KEY\_KATAKANAHIRAGANA

- 20 (0x14)

Key name KEY\_LEFTCTRL

- 21 (0x15)

Key name KEY\_Q

- 22 (0x16)

Key name KEY\_1

- 26 (0x1a)

Key name KEY\_Z

- 27 (0x1b)

Key name KEY\_S

- 28 (0x1c)

Key name KEY\_A

- 29 (0x1d)

Key name KEY\_W

- 30 (0x1e)

Key name KEY\_2

- 33 (0x21)

Key name KEY\_C

- 34 (0x22)

Key name KEY\_X

- 35 (0x23)

Key name KEY\_D

- 36 (0x24)

Key name KEY\_E

- 37 (0x25)

Key name KEY\_4

- 38 (0x26)

Key name KEY\_3

- 39 (0x27)

Key name KEY\_KPJPCOMMA

- 41 (0x29)

Key name KEY\_SPACE

- 42 (0x2a)

Key name KEY\_V

- 43 (0x2b)

Key name KEY\_F

- 44 (0x2c)

Key name KEY\_T

- 45 (0x2d)

Key name KEY\_R

- 46 (0x2e)

Key name KEY\_5

- 47 (0x2f)

Key name KEY\_F13

- 49 (0x31)

Key name KEY\_N

- 50 (0x32)

Key name KEY\_B

- 51 (0x33)

Key name KEY\_H

- 52 (0x34)

Key name KEY\_G

- 53 (0x35)

Key name KEY\_Y

- 54 (0x36)

Key name KEY\_6

- 55 (0x37)

Key name KEY\_F14

- 58 (0x3a)

Key name KEY\_M

- 59 (0x3b)

Key name KEY\_J

- 60 (0x3c)

Key name KEY\_U

- 61 (0x3d)

Key name KEY\_7

- 62 (0x3e)

Key name KEY\_8

- 63 (0x3f)

Key name KEY\_F15

- 65 (0x41)

Key name KEY\_COMMA

- 66 (0x42)

Key name KEY\_K

- 67 (0x43)

Key name KEY\_I

- 68 (0x44)

Key name KEY\_O

- 69 (0x45)

Key name KEY\_0

- 70 (0x46)

Key name KEY\_9

- 73 (0x49)

Key name KEY\_DOT

- 74 (0x4a)

Key name KEY\_SLASH

- 75 (0x4b)

Key name KEY\_L

- 76 (0x4c)

Key name KEY\_SEMICOLON

- 77 (0x4d)

Key name KEY\_P

- 78 (0x4e)

Key name KEY\_MINUS

- 81 (0x51)

Key name KEY\_RO

- 82 (0x52)

Key name KEY\_APOSTROPHE

- 84 (0x54)

Key name KEY\_LEFTBRACE

- 85 (0x55)

Key name KEY\_EQUAL

- 88 (0x58)

Key name KEY\_CAPSLOCK

- 89 (0x59)

Key name KEY\_RIGHTSHIFT

- 90 (0x5a)

Key name KEY\_ENTER

- 91 (0x5b)

Key name KEY\_RIGHTBRACE

- 93 (0x5d)

Key name KEY\_BACKSLASH

- 95 (0x5f)

Key name KEY\_ZENKAKUHANKAKU

- 97 (0x61)

Key name KEY\_102ND

- 98 (0x62)

Key name KEY\_HIRAGANA

- 99 (0x63)

Key name KEY\_KATAKANA

- 100 (0x64)

Key name KEY\_HENKAN

- 102 (0x66)

Key name KEY\_BACKSPACE

- 103 (0x67)

Key name KEY\_MUHENKAN

- 105 (0x69)

Key name KEY\_KP1

- 106 (0x6a)

Key name KEY\_YEN

- 107 (0x6b)

Key name KEY\_KP4

- 108 (0x6c)

Key name KEY\_KP7

- 109 (0x6d)

Key name KEY\_KPCOMMA

- 112 (0x70)

Key name KEY\_KP0

- 113 (0x71)

Key name KEY\_KPDOT

- 114 (0x72)

Key name KEY\_KP2

- 115 (0x73)

Key name KEY\_KP5

- 116 (0x74)

Key name KEY\_KP6

- 117 (0x75)

Key name KEY\_KP8

- 118 (0x76)

Key name KEY\_ESC

- 119 (0x77)

Key name KEY\_NUMLOCK

- 120 (0x78)

Key name KEY\_F11

- 121 (0x79)

Key name KEY\_KPPLUS

- 122 (0x7a)

Key name KEY\_KP3

- 123 (0x7b)

Key name KEY\_KPMINUS

- 124 (0x7c)

Key name KEY\_KPASTERISK

- 125 (0x7d)

Key name KEY\_KP9

- 126 (0x7e)

Key name KEY\_SCROLLLOCK

- 127 (0x7f)

Key name KEY\_SYSRQ

- 131 (0x83)

Key name KEY\_F7

- 57360 (0xe010)

Key name KEY\_SEARCH

- 57361 (0xe011)

Key name KEY\_RIGHTALT

- 57362 (0xe012)

Key name unnamed

- 57364 (0xe014)

Key name KEY\_RIGHTCTRL

- 57365 (0xe015)

Key name KEY\_PREVIOUSSONG

- 57368 (0xe018)

Key name KEY\_BOOKMARKS

- 57375 (0xe01f)

Key name KEY\_LEFTMETA

- 57376 (0xe020)

Key name KEY\_REFRESH

- 57377 (0xe021)

Key name KEY\_VOLUMEDOWN

- 57379 (0xe023)

Key name KEY\_MUTE

- 57383 (0xe027)

Key name KEY\_RIGHTMETA

- 57384 (0xe028)

Key name KEY\_STOP

- 57387 (0xe02b)

Key name KEY\_CALC

- 57391 (0xe02f)

Key name KEY\_COMPOSE

- 57392 (0xe030)

Key name KEY\_FORWARD

- 57394 (0xe032)

Key name KEY\_VOLUMEUP

- 57396 (0xe034)

Key name KEY\_PLAYPAUSE

- 57399 (0xe037)

Key name KEY\_POWER

- 57400 (0xe038)

Key name KEY\_BACK

- 57402 (0xe03a)

Key name KEY\_HOMEPAGE

- 57403 (0xe03b)

Key name KEY\_STOPCD

- 57407 (0xe03f)

Key name KEY\_SLEEP

- 57408 (0xe040)

Key name KEY\_COMPUTER

- 57416 (0xe048)

Key name KEY\_MAIL

- 57418 (0xe04a)

Key name KEY\_KPSLASH

- 57421 (0xe04d)



Key name KEY\_NEXTSONG

- 57424 (0xe050)

Key name KEY\_MEDIA

- 57434 (0xe05a)

Key name KEY\_KPENTER

- 57438 (0xe05e)

Key name KEY\_WAKEUP

- 57449 (0xe069)

Key name KEY\_END

- 57451 (0xe06b)

Key name KEY\_LEFT

- 57452 (0xe06c)

Key name KEY\_HOME

- 57455 (0xe06f)

Key name KEY\_MACRO

- 57456 (0xe070)

Key name KEY\_INSERT

- 57457 (0xe071)

Key name KEY\_DELETE

- 57458 (0xe072)

Key name KEY\_DOWN

- 57460 (0xe074)

Key name KEY\_RIGHT

- 57461 (0xe075)

Key name KEY\_UP

- 57463 (0xe077)

Key name KEY\_PAUSE

- 57465 (0xe079)

Key name KEY\_KPPLUSMINUS

- 57466 (0xe07a)

Key name KEY\_PAGEDOWN

- 57469 (0xe07d)

Key name KEY\_PAGEUP