

NAME

sane-ma1509 – SANE backend for Mustek BearPaw 1200F USB scanner

DESCRIPTION

The **sane-ma1509** library implements a SANE (Scanner Access Now Easy) backend that provides access to the Mustek BearPaw 1200F USB flatbed scanner. This scanner is based on the MA-1509 chipset. Other scanners that use this chip (if they exist) may also work.

This backend is ALPHA software. Be careful and remove the power plug immediately if you hear unusual noises.

More details can be found on the ma1509 backend homepage <http://www.meier-geinitz.de/sane/ma1509-backend/>.

Other Mustek USB scanners are supported by the gt68xx, mustek_usb and the plustek backends. See **sane-mustek_usb(5)**, **sane-gt68xx(5)** and **sane-plustek(5)** for details.

This backend can only work with scanners that are already detected by the operating system. See **sane-usb(5)** for details.

If you own a scanner other than the Mustek BearPaw 1200F that works with this backend, please let me know this by sending the scanner's exact model name and the USB vendor and device ids (e.g. from `/proc/bus/usb/devices` or `syslog`) to me.

DEVICE NAMES

This backend expects device names of the form:

special

Where *special* is a path-name for the special device that corresponds to a USB scanner. With Linux, such a device name could be `/dev/usb/scanner0` or `libusb:001:002`, for example.

CONFIGURATION

The contents of the `ma1509.conf` file is a list of options and device names that correspond to Mustek BearPaw 1200F scanners. Empty lines and lines starting with a hash mark (#) are ignored.

Instead of using the device name, the scanner can be autodetected by **usb vendor_id product_id** statements which are already included into `ma1509.conf`. This is only supported with Linux 2.4.8 and higher and all systems that support libsub. "vendor_id" and "product_id" are hexadecimal numbers that identify the scanner. If this doesn't work, a device name must be placed in `ma1509.conf` as described above.

To set the time the lamp needs for warm-up, use **option warmup-time** in `ma1509.conf`. The time is given in seconds after the option. The default is 30 seconds.

FILES

@*CONFIGDIR*@/`ma1509.conf`

The backend configuration file (see also description of **SANE_CONFIG_DIR** below).

@*LIBDIR*@/`libsane-ma1509.a`

The static library implementing this backend.

@*LIBDIR*@/`libsane-ma1509.so`

The shared library implementing this backend (present on systems that support dynamic loading).

ENVIRONMENT**SANE_CONFIG_DIR**

This environment variable specifies the list of directories that may contain the configuration file. Under UNIX, the directories are separated by a colon (:), under OS/2, they are separated by a semi-colon (;). If this variable is not set, the configuration file is searched in two default directories: first, the current working directory (".") and then in @*CONFIGDIR*@. If the value of the environment variable ends with the directory separator character, then the default directories are searched after the explicitly specified directories. For example, setting **SANE_CONFIG_DIR** to `/tmp/config:` would result in directories `tmp/config`, `.`, and `@CONFIGDIR@` being

searched (in this order).

SANE_DEBUG_MA1509

If the library was compiled with debug support enabled, this environment variable controls the debug level for this backend. Higher debug levels increase the verbosity of the output.

SEE ALSO

sane(7), **sane-usb(5)**, **sane-gt68xx(5)**, **sane-plustek(5)**, **sane-mustek_usb(5)**, **sane-mustek(5)**, **sane-mustek_pp(5)**,
<http://www.meier-geinitz.de/sane/ma1509-backend/>

AUTHOR

Henning Meier-Geinitz <henning@meier-geinitz.de>

BUGS

Resolutions higher than 600 dpi don't work

Transparency adapter and automatic document feeder is not supported yet

No support for "high-speed" mode (jpeg)

More detailed bug information is available at the MA-1509 backend homepage
<http://www.meier-geinitz.de/sane/ma1509-backend/>.