

Full credit is given to the above companies including the Operating System (OS) that this PDF file was generated!

Rocky Enterprise Linux 9.2 Manual Pages on command 'sane-canon_lide70.5'

\$ man sane-canon_lide70.5

sane-canon_lide70(5)

DESCRIPTION

SANE Scanner Access Now Easy

sane-canon_lide70(5)

NAME

sane-canon_lide70 - SANE backend for the Canon LiDE 70 and 600(F) USB flatbed scanners

The canon_lide70 library implements a SANE (Scanner Access Now Easy) backend that provides access to the Canon Inc. CanoScan LiDE 70 and 600(F) flatbed scanners. The film unit of

the LiDE 600F is not supported.

Due to Canon's unwillingness to provide scanner documentation, this software was developed by analyzing the USB traffic of the Windows XP driver. The precise meaning of the individ? ual commands that are sent to the scanner is known only to a very limited extent. Some so? phistication present in the Windows XP driver has been left out. There is, for example, no active calibration.

Testers and reviewers are welcome. Send your bug reports and comments to the sane-devel mailing list <sane-devel@alioth-lists.debian.net>.

CONFIGURATION

The /etc/sane.d/canon_lide70.conf file identifies the LiDE 70 by its vendor code 0x04a9 and its product code 0x2225. For the LiDE 600(f) the product code is 0x2224.

BACKEND SPECIFIC OPTIONS

Scan Mode:

--resolution 75|150|300|600|1200 [default 600]

Sets the resolution of the scanned image in dots per inch. Scanning at 1200 dpi is not available on the LiDE 600(F) and it is very slow on the LiDE 70.

Selects the scan mode. Lineart means fully black and fully white pixels only.

--threshold 0..100 (in steps of 1) [default 75]

Select minimum-brightness percentage to get a white point, relevant only for Lin? eart

--non-blocking[=(yes|no)] [inactive]

This option has not yet been implemented. Scans are captured in a temporary file with a typical size of 100MB.

Geometry:

-I 0..216.069 [default 0]

Top-left x position of scan area in millimeters.

-t 0..297 [default 0]

Top-left y position of scan area in millimeters.

-x 0..216.069 [default 80]

Width of scan-area in millimeters.

-y 0..297 [default 100]

Height of scan-area in millimeters.

FILES

/etc/sane.d/canon lide70.conf

The backend configuration file

/usr/lib/x86_64-linux-gnu/sane/libsane-canon_lide70.a

The static library implementing this backend.

/usr/lib/x86_64-linux-gnu/sane/libsane-canon_lide70.so

The shared library implementing this backend (present on systems that support dy? namic loading).

ENVIRONMENT

SANE DEBUG CANON LIDE70

If the library was compiled with debug support enabled, this environment variable controls the debug level for this backend. Higher debug levels increase the ver? bosity of the output.

Example:

SANE_DEBUG_CANON_LIDE70=128 scanimage > /dev/null

KNOWN PROBLEMS

top one millimeter of the scan area. This can be remedied by shifting the document one millimeter downward, in cases where such precision matters. Note that xsane(1) uses the 75 dpi mode for prescans. The problem is worse on the LiDE 600(F), where the offset is five millimeters.

SEE ALSO

sane(7), sane-usb(5), sane-find-scanner(1), scanimage(1), xsane(1),
http://www.juergen-ernst.de/info_sane.html

AUTHOR

pimvantend, building upon pioneering work by Juergen Ernst.

22 Aug 2020

sane-canon_lide70(5)