Red Hat Enterprise Linux Release 9.2 Manual Pages on 'nvme-boot-part-log.1' command

$ man nvme-boot-part-log.1

NVME-BOOT-PART-LO(1)   NVMe Manual   NVME-BOOT-PART-LO(1)

NAME

   nvme-boot-part-log - Retrieves a Boot Partition log page from an NVMe

   device

SYNOPSIS

   nvme boot-part-log <device> [--lsp=<field> | -s <field>]

             [--output-file=<file> | -o <file>]

             [--output-format=<fmt> | -o <fmt>]

DESCRIPTION

   Retrieves an Boot Partition log page from an NVMe device and provides

   the returned structure.

   The <device> parameter is mandatory and may be either the NVMe

   character device (ex: /dev/nvme0), or a namespace block device (ex:

   /dev/nvme0n1).

   On success, the returned log structure will be in raw binary format

   only with --output-file option which is mandatory.

OPTIONS

   -s <field>, --lsp=<field>

      The log specified field of LID.

   -o <file>, --output-file=<file>

      File name to which raw binary data will be saved to.

   -o <format>, --output-format=<format>

      Set the reporting format to normal, json, or binary. Only one

output format can be used at a time.

EXAMPLES

? Retrieve Boot Partition data to boot_part_log.bin

nvme boot-part-log /dev/nvme0 --output-file=boot_part_log.bin

NVME

Part of the nvme-user suite

NVMe   06/23/2023   NVME-BOOT-PART-LO(1)