Red Hat Enterprise Linux Release 9.2 Manual Pages on 'nvme-ocp-smart-add-log.1' command

$ man nvme-ocp-smart-add-log.1

NVME-OCP-SMART-AD(1)   NVMe Manual   NVME-OCP-SMART-AD(1)

NAME

    nvme-ocp-smart-add-log - Retrieves Extended SMART information of given

    OCP compliant device

SYNOPSIS

    nvme ocp smart-add-log <device> [--output-format=<fmt> | -o <fmt>]

DESCRIPTION

    For the NVMe device given, send a smart-add-log command and provide the

    additional smart log.

    The <device> parameter is mandatory and may be either the NVMe

    character device (ex: /dev/nvme0) or block device (ex: /dev/nvme0n1).

    This will only work on OCP compliant devices supporting this feature.

    Results for any other device are undefined.

    On success it returns 0, error code otherwise.

OPTIONS

    -o <format>, --output-format=<format>

      Set the reporting format to normal or json. Only one output format

      can be used at a time. The default is normal.

EXAMPLES

    ?   Has the program issue a smart-add-log command to retrieve the 0xC0

    log page.

      # nvme ocp smart-add-log /dev/nvme0

NVME

Part of the nvme-user suite.