Red Hat Enterprise Linux Release 9.2 Manual Pages on 'nvme-wdc-log-page-directory.1' command

$ man nvme-wdc-log-page-directory.1

NVME-WDC-LOG-PAGE(1)   NVMe Manual   NVME-WDC-LOG-PAGE(1)

NAME

    nvme-wdc-log-page-directory - Retrieves the list of Log IDs supported

    by the drive

SYNOPSIS

    nvme wdc log-page-directory <device> [--output-format=<normal|json|binary> -o <normal|json|binary>]

DESCRIPTION

    For the NVMe device given, retrieves the log page directory which

    contains the list of log page IDs supported by the drive. The

    --output-format option will format the output as specified.

    The <device> parameter is mandatory and must be the NVMe character

    device (ex: /dev/nvme0).

    This will only work on WDC devices supporting this feature. Results for

    any other device are undefined.

    On success it returns the log page directory information, error code

    otherwise.

OPTIONS

    -o <format>, --output-format=<format>

        Set the reporting format to normal, json, or binary. Only one

        output format can be used at a time. The default is normal.

EXAMPLES

    ? WDC log-page-directory example command :

        # nvme wdc log-page-directory /dev/nvme0

NVME

Part of the nvme-user suite.