



Full credit is given to the above companies including the OS that this PDF file was generated!

Red Hat Enterprise Linux Release 9.2 Manual Pages on 'nvme-wdc-vs-drive-info.1' command

\$ man nvme-wdc-vs-drive-info.1

NVME-WDC-VS-DRIVE(1) NVMe Manual NVME-WDC-VS-DRIVE(1)

NAME

nvme-wdc-vs-drive-info - Send the NVMe WDC vs-drive-info command,
return result

SYNOPSIS

nvme wdc vs-drive-info <device>

DESCRIPTION

For the NVMe device given, send the unique WDC vs-drive-info command
and provide the additional drive information.

The <device> parameter is mandatory and must be the NVMe character
device (ex: /dev/nvme0).

This will only work on WDC devices supporting this feature. Results for
any other device are undefined.

On success it returns 0, error code otherwise.

OUTPUT EXPLANATION

There are several different fields returned from this command depending
on the drive:

Drive HW Revision

FTL Unit Size

Customer Serial Number

HyperScale Boot Version

TCG Device Ownership

EXAMPLE

nvme wdc vs-drive-info /dev/nvme0

NVME

Part of the nvme-user suite.

NVMe 06/23/2023 NVME-WDC-VS-DRIVE(1)