



*Full credit is given to the above companies including the OS that this PDF file was generated!*

### ***Rocky Enterprise Linux 9.2 Manual Pages on command 'nvme-boot-part-log.1'***

**\$ man nvme-boot-part-log.1**

NVME-BOOT-PART-LO(1) NVMe Manual NVME-BOOT-PART-LO(1)

#### **NAME**

nvme-boot-part-log - Retrieves a Boot Partition log page from an NVMe

device

#### **SYNOPSIS**

nvme boot-part-log <device> [--lsp=<field> | -s <field>]

[--output-file=<file> | -o <file>]

[--output-format=<fmt> | -o <fmt>]

#### **DESCRIPTION**

Retrieves an Boot Partition log page from an NVMe device and provides the returned structure.

The <device> parameter is mandatory and may be either the NVMe character device (ex: /dev/nvme0), or a namespace block device (ex: /dev/nvme0n1).

On success, the returned log structure will be in raw binary format only with --output-file option which is mandatory.

#### **OPTIONS**

-s <field>, --lsp=<field>

The log specified field of LID.

-o <file>, --output-file=<file>

File name to which raw binary data will be saved to.

-o <format>, --output-format=<format>

Set the reporting format to normal, json, or binary. Only one

output format can be used at a time.

## EXAMPLES

? Retrieve Boot Partition data to boot\_part\_log.bin

```
# nvme boot-part-log /dev/nvme0 --output-file=boot_part_log.bin
```

## NVME

Part of the nvme-user suite

NVMe 06/23/2023 NVME-BOOT-PART-LO(1)