



Full credit is given to the above companies including the OS that this PDF file was generated!

Rocky Enterprise Linux 9.2 Manual Pages on command 'nvme-micron-nand-stats.1'

\$ man nvme-micron-nand-stats.1

NVME-MICRON-NAND-(1) NVMe Manual NVME-MICRON-NAND-(1)

NAME

nvme-micron-nand-stats - Retrieves NAND statistics of given micron device

SYNOPSIS

nvme micron vs-nand-stats <device>

DESCRIPTION

This command prints NAND information (Total bytes written, Bad block count and Erase failures etc) for the given micron device.

The <device> parameter is mandatory and may be either the NVMe character device (ex: /dev/nvme0), or a namespace block device (ex: /dev/nvme0n1).

This will only work on Micron devices devices of model numbers 54XX.
Support for new devices may be added subsequently.

OPTIONS

None

EXAMPLES

? Retrieve NAND statistics information

nvme micron vs-nand-stats /dev/nvme0

NVME

Part of the nvme-user suite

NVMe 06/23/2023 NVME-MICRON-NAND-(1)