



Rocky Enterprise Linux 9.2 Manual Pages on command 'nvme-seagate-vs-internal-log.1'

\$ man nvme-seagate-vs-internal-log.1

NVME-SEAGATE-VS-I(1) NVMe Manual NVME-SEAGATE-VS-I(1)

NAME

nvme-seagate-vs-internal-log - Retrieve Seagate vendor specific
Controller-Initiated Telemetry in binary

SYNOPSIS

nvme seagate vs-internal-log <device> [OPTIONS]

DESCRIPTION

This command will only work on Seagate devices supporting this feature.
Not all commands work across all product families.
The <device> parameter is mandatory and may be either an NVMe character
device (ex: /dev/nvme0) or an nvme block device (ex: /dev/nvme0n1).

OPTIONS

-n <NUM>, --namespace-id=<NUM>
Desired namespace
-f <FILE>, --dump-file=<FILE>
Dump file

EXAMPLES

Get the Seagate vendor specific Controller-Initiated telemetry log for

the specified device.

```
# nvme seagate vs-internal-log /dev/nvme0
```

NVME

Part of the nvme-user suite

NVMe	06/23/2023	NVME-SEAGATE-VS-I(1)
------	------------	----------------------