



Full credit is given to the above companies including the OS that this PDF file was generated!

Rocky Enterprise Linux 9.2 Manual Pages on command 'nvme-seagate-vs-log-page-sup.1'

\$ man nvme-seagate-vs-log-page-sup.1

NVME-SEAGATE-VS-L(1) NVMe Manual NVME-SEAGATE-VS-L(1)

NAME

nvme-seagate-vs-log-page-sup - Retrieve Seagate vendor specific Supported Log-pages Information

SYNOPSIS

nvme seagate vs-log-page-sup <device> [OPTIONS]

DESCRIPTION

This command will only work on Seagate devices supporting this feature.

Not all commands work across all product families.

The <device> may be either an NVMe character device (ex: /dev/nvme0) or an NVMe block device (ex: /dev/nvme0n1).

OPTIONS

-o <FMT>, --output-format=<FMT>

Output in binary format

EXAMPLES

Get the vendor specific log page information for a particular device.

```
# nvme seagate vs-log-page-sup /dev/nvme0
```

Output:

Seagate Supported Log-pages count :8

LogPage-Id	LogPage-Name
0x1	ERROR_INFORMATION
0x2	SMART_INFORMATION
0x3	FW_SLOT_INFORMATION
0x5	COMMANDS_SUPPORTED_AND_EFFECTS
0xC8	VS_RECENT_DRIVE_HISTORY
0xC4	VS_EXTENDED_SMART_INFO
0xC5	VS_LIST_SUPPORTED_LOG_PAGE
0xCB	VS_PCIE_ERROR_LOG_PAGE

NVME

Part of the nvme-user suite

NVMe	06/23/2023	NVME-SEAGATE-VS-L(1)
------	------------	----------------------