



Full credit is given to the above companies including the OS that this PDF file was generated!

Rocky Enterprise Linux 9.2 Manual Pages on command 'nvme-wdc-get-latency-monitor-log.1'

\$ man nvme-wdc-get-latency-monitor-log.1

NVME-WDC-GET-LATE(1) NVMe Manual NVME-WDC-GET-LATE(1)

NAME

nvme-wdc-get-latency-monitor-log - Display latency monitor log page data in human readable format

SYNOPSIS

nvme wdc get-latency-monitor-log <device> [--output-format=<normal|json> -o <normal|json>]

DESCRIPTION

For the NVMe device given, latency monitor log page data.
The <device> parameter is mandatory NVMe character device (ex: /dev/nvme0).
This will only work on WDC devices supporting this log page. Results for any other device are undefined.
On success it returns 0, error code otherwise.

OPTIONS

-o <format>, --output-format=<format>
Set the reporting format to normal or json. Only one output format can be used at a time. The default is normal.

EXAMPLES

? Displays the get latency monitor log for the device:

```
# nvme wdc get-latency-monitor-log /dev/nvme0
```

NVME

Part of the nvme-user suite.

| | | |
|------|------------|----------------------|
| NVMe | 06/23/2023 | NVME-WDC-GET-LATE(1) |
|------|------------|----------------------|